

**Environmental Mitigation Implementation Schedule  
WENT Landfill Extension**

**Appendix C9 – Pulverized Fuel Ash Impact**

EIA Ref	EM&A Log Ref	Recommended Mitigation Measures (to be implemented when the trigger level is exceeded, where necessary)	Objectives of Recommended Measures & Main Concerns to Address	Who to Implement Measures?	Location of Measures	When to Implement Measures?	What Requirements or Standards for Measures to Achieve?
<b><i>Pulverized Fuel Ash Impact</i></b>							
<b><i>Construction and Operation Phases</i></b>							
S11.5	PF1	Recommended measures/ good practices are to be considered	To control radon health risk	DBO Contractor	Entire WENT Landfill Extension site	Construction and Operation phases	<i>ProPECC Note PN 1/99 Control of Radon Concentration in New Buildings</i>