



隔油池的兩個側視圖，圖中顯示了頂部的廢油脂層和底部的沉積廢物層

TWO VIEWS OF A GREASE TRAP WHICH SHOW THE TOP LAYER OF GREASY WASTE AND THE BOTTOM LAYER OF SETTLED SOLIDS



出水口末端  
OUTLET END



入水口末端  
INLET END

隔油池示意圖之圖例

KEY TO GREASE TRAP ILLUSTRATION ON FACING PAGE

All dimensions in millimeters

$W$  = width  $W < L_1 < L_2 < 2000$   
 $L_T$  = total length =  $L_1 + L_2$   
 $L_1$  = length of first chamber  
 $L_2$  = length of second chamber  
 $H_T$  = total depth =  $H_L + H_s \leq 1800$   
 $H_L$  = liquid depth  $\leq 1200$   
 $H_s$  = head space =  $1/3 H_T$   
 CAPACITY =  $\frac{W \times L_T \times H_L}{1,000,000} \geq 250$  Litres

$1.3 \leq L_T \div H_T \leq 2.0$   
 $1000 \leq W \times L_T \div H_T \leq 2000$

$d$  = pipe diameter  $\geq 100$

All baffles placed distance  $d+50$  from trap wall

All baffles extend  $1.5d$  above liquid surface

$A$  = inlet baffle depth  
 =  $3d$  OR  $2/3 H_L$ , whichever is greater  
 but  $\leq 500$

Diameter of vent holes and pipes  $\geq 80$

尺寸均以毫米為單位

$W$  = 寬度  $W < L_1 < L_2 < 2000$   
 $L_T$  = 總長度 =  $L_1 + L_2$   
 $L_1$  = 第一隔間長度  
 $L_2$  = 第二隔間長度  
 $H_T$  = 總深度 =  $H_L + H_s \leq 1800$   
 $H_L$  = 液體深度  $\leq 1200$   
 $H_s$  = 頂高 =  $1/3 H_T$   
 容量 =  $\frac{W \times L_T \times H_L}{1,000,000} \geq 250$  升

$1.3 \leq L_T \div H_T \leq 2.0$   
 $1000 \leq W \times L_T \div H_T \leq 2000$

$d$  = 管徑  $\geq 100$

所有隔板應距池邊  $d+50$  (壹個管徑+50) 的距離

所有隔板應高於液面  $1.5d$  (壹個半管徑) 的距離

$A$  = 入水口隔板的深度  
 =  $3d$  或  $2/3 H_L$  以較大者為準  
 但  $\leq 500$

通風口及管的直徑  $\geq 80$