

Appendix 5.2 Mathematical Expressions for Pile Frictions

- 5.1.1 The mathematical expressions for representation of pile friction are based on the Delft 3D-FLOW module developed by Delft Hydraulics. A quadratic friction term added to the momentum equations can be expressed in the form:

$$\begin{aligned} \text{Friction loss in the u coordinate direction} &= [C_{\text{loss, u}} U |<U>|] / \Delta x \text{ (m/s}^2\text{)} \\ \text{Friction loss in the v coordinate direction} &= [C_{\text{loss, v}} V |<U>|] / \Delta y \text{ (m/s}^2\text{)} \dots\dots\dots (1.1) \end{aligned}$$

Where:

- $C_{\text{loss, u}}$ and $C_{\text{loss, v}}$ = loss coefficients in the u and v coordinate directions;
- $<U>$ = velocity vector (U, V);
- $|<U>|$ = magnitude of the velocity vector = $\sqrt{U^2 + V^2}$ (m/s); and
- Δx and Δy = grid distances in u and v coordinate directions respectively (m).

- 5.1.2 According to the water speeds in each model layer, the additional quadratic friction term influences the horizontal flow distribution in each layer and so indirectly affects the vertical turbulent exchange.

- 5.1.3 The force exerted on the vertical section (Δz) of one pile can be expressed as:

Drag force on a pile in the u coordinate direction:

$$F_u = C_d \frac{1}{2} \rho D U_e |<U_e>| \Delta z$$

Drag force on a pile in the v coordinate direction:

$$F_v = C_d \frac{1}{2} \rho D V_e |<U_e>| \Delta z \dots\dots\dots (1.2)$$

Where:

- C_d = drag coefficient;
- ρ = density of water (kg/m³);
- $<U_e>$ = effective approach velocity vector (U_e, V_e) (m/s);
- $|<U_e>|$ = magnitude of the effective approach velocity vector = $\sqrt{U_e^2 + V_e^2}$ (m/s);
- D = diameter of the pile (m); and
- Δz = length of the vertical section (m).

- 5.1.4 The effective approach velocity can be calculated using the wet cross section as seen in flow direction and is expressed as:

$$\text{Effective approach velocity } <U_e> = <U> \times [A_T / A_e] = <U> \times a \dots\dots\dots (1.3)$$

Where:

- A_T = total cross-sectional area (m²);
- A_e = effective wet cross sectional area
- = total cross-sectional area (A_T) – area blocked by the pile (m²); and
- a = ratio of the total area to the effective area.

- 5.1.5 Assuming the piles are not in the shadow of each other, the total force exerted on the vertical section for n numbers of piles can be expressed as:

Total drag force in the u coordinate direction:

$$F_{\text{tot, u}} = n C_d \frac{1}{2} \rho D U_e |<U_e>| \Delta z$$

Total drag force in the v coordinate direction:

$$F_{tot,v} = n C_d \frac{1}{2} \rho D V_e |<U_e>| \Delta z$$

Where: n = number of piles in the control grid cell

5.1.6 The total friction loss term in the u and v coordinate directions can be determined by dividing the forces by the mass in the control volume (= $\rho \Delta x \Delta y \Delta z$) and can be expressed as:

$$\text{Total friction loss in the x-direction} = n C_d \frac{1}{2} D U_e |<U_e>| \Delta z \frac{|<U_e>|}{(\Delta x \Delta y)}$$

$$\text{Total friction loss in the y-direction} = n C_d \frac{1}{2} D V_e |<U_e>| \Delta z \frac{|<U_e>|}{(\Delta x \Delta y)} \dots\dots\dots (1.4)$$

5.1.7 Combining Equation (1.1) and Equation (1.4), the loss coefficients for n numbers of piles in the u and v coordinate directions are:

$$\text{Loss coefficient in the u coordinate direction } C_{loss,u} = [n C_d \frac{1}{2} D a^2] / (\Delta y)$$

$$\text{Loss coefficient in the v coordinate direction } C_{loss,v} = [n C_d \frac{1}{2} D a^2] / (\Delta x) \dots\dots\dots (1.5)$$

5.1.8 Based on the equations (1.1) – (1.5), the loss coefficients were calculated for relevant model grid cells in both u and v directions for model input.